

1 Bundles with BDI1000

- 30163 BDI1000 with software bdiRDI for ARM7/9/9E targets
1 BDI1000 BDM/JTAG Interface including Software bdiRDI (Interface Software for ADW/AXD from ARM). Supports debugging via RS232 and Ethernet.
- 30180 BDI1000 with software bdiRDI for XScale targets
1 BDI1000 BDM/JTAG Interface including Software bdiRDI (Interface Software for ADW/AXD from ARM). Supports debugging via RS232 and Ethernet.

2 Bundles with BDI2000

- 30164 BDI2000 with software bdiRDI, ARM7/9/9E targets
1 BDI2000 high-speed BDM/JTAG Interface including Software bdiRDI (Interface Software for ADW/AXD from ARM). Supports debugging via RS232 and Ethernet.
- 30183 BDI2000 with software bdiRDI, ARM11 targets
1 BDI2000 high-speed BDM/JTAG Interface including Software bdiRDI (Interface Software for ADW/AXD from ARM). Supports debugging via RS232 and Ethernet.
- 30181 BDI2000 with software bdiRDI, XScale targets
1 BDI2000 high-speed BDM/JTAG Interface including Software bdiRDI (Interface Software for ADW/AXD from ARM). Supports debugging via RS232 and Ethernet.

3 Power Supplies (not included in Bundles)

- 20300 Power Supply for BDI1000/2000, 100-240V/50-60Hz, Euro connector
- 20301 Power Supply for BDI1000/2000, 100-240V/50-60Hz, US connector
- 20302 Power Supply for BDI1000/2000, 100-240V/50-60Hz, UK connector
- 20303 Power Supply for BDI1000/2000, 100-240V/50-60Hz, AUS connector
- 20304 Power Supply for BDI1000/2000, 100-240V/50-60Hz, ASIA (US) connector

4 Software for BDI1000 (for additional Targets including Target Cable)

- 20190-4 Software bdiRDI for BDI1000, ARM7/9/9E targets, 1 license
- 20270-4 Software bdiRDI for BDI1000, XScale targets, 1 license

5 Software for BDI2000 (for additional Targets including Target Cable)

- 20190-3 Software bdiRDI for BDI2000, ARM7/9/9E targets, 1 license
- 20271-3 Software bdiRDI for BDI2000, ARM11 targets, 1 license
- 20270-3 Software bdiRDI for BDI2000, Xscale targets, 1 license

Warranty and Support:

- 3 years hardware warranty
- 1 year software warranty / support